

SCHEDULE

ACTION PROGRAMME

- 14.** Field middens must be sited at least–
- (a) 10 metres from any inland or coastal waters; or
 - (b) 50 metres from any well, borehole or similar work sunk into underground strata for the purposes of any water supply.