

## SCHEDULE

<i>Class of fireplace</i>	<i>Conditions</i>
The Cronspisen stove, using the five channel chimney system, manufactured by Cronspisen Produktion AB.	<ol style="list-style-type: none"><li>1. The fireplace is installed, maintained and operated in accordance with the manufacturer's instructions bearing the reference "January 1992. Serial No: UM 351B".</li><li>2. No fuel is used other than firewood that has been split, stacked and air-dried.</li></ol>
The RanHeat Boiler Types RHA 160, 200 and 250, manufactured by RanHeat Energy GB Limited.	<ol style="list-style-type: none"><li>1. The fireplaces are installed, maintained and operated in accordance with the manufacturer's instructions dated 30th March 1988 bearing the reference "RHGBEA 30388".</li><li>2. No fuel is used other than hard and soft wood shavings.</li></ol>
The Defiant Encore manufactured by VCW International Limited.	<ol style="list-style-type: none"><li>1. The fireplace is installed, maintained and operated in accordance with the manufacturer's instructions dated November 1991 bearing the reference "200—8632".</li><li>2. No fuel is used other than firewood that has been split, stacked and air-dried.</li></ol>