

SCHEDULE 4

LIFERAFTS

PART VIII

GAS INFLATION SYSTEM

High Pressure Hose Assembly

6.7 The hose shall operate in a satisfactory manner throughout an air temperature range of -45°C to $+65^{\circ}\text{C}$.