SCHEDULE

CLASSES OF FIREPLACE WHICH ARE EXEMPT

1. The fireplace must be installed, maintained and operated in accordance with the manufacturer's instruction manual, reference PM 249 Issue 1.

A permanent stop must be in place on the secondary inlet to prevent closure beyond the 75% open position.