Status: This is the original version (as it was originally made). This item of legislation is currently only available in its original format.

SCHEDULE 3

(Annex III to Directive 97/68/EC) TEST PROCEDURE **Status:** This is the original version (as it was originally made). This item of legislation is currently only available in its original format.

Appendix 2

CO analyser interference check

1.9.1. Water and CO_2 can interfere with the CO analyser performance. Therefore a CO_2 span gas having a concentration of 80 to 100% of full scale of the maximum operating range used during testing shall be bubbled through water at room temperature and the analyser response recorded. The analyser response must not be more than 1% of full scale for ranges equal to or above 300 ppm or more than 3 ppm for ranges below 300 ppm.